



iZone® Product Cleaning and Maintenance

Cleaning

- Mild soap and water is always best for general cleaning. Rinse with clean water after washing. DO NOT use abrasive cleaners, acids or acetone. They will damage the surface of the panel.
- Graffiti (paint, crayon, felt tip markers, etc) can be removed using organic solvents, such as *Simple Green*®, *Goof-Off*®, or similar non-abrasive, citrus-based cleaners.
- Very stubborn graffiti may require stronger solvents, such as mineral spirits. DO NOT use lacquer thinner or acetone, as they will damage the surface of the panel. Always rinse with clean water after cleaning.
- Minor blemishes, nicks, abrasions, burns, or light scratches can be concealed using a polymer-based boat or car wax.

Maintenance

- Edges should be wiped with a liquid wax, like *Thompson's Water Seal* annually. This helps re-moisturize the core edges and maintains the black color of the edge.
- Occasionally wiping a cleaned graphic face with a polymer-based boat or car wax will assist in removal of graffiti and dirt.